



Original	Sustituto	Original	Sustituto
Power	Power	CH+	Ch +
Source	AV	CH-	Ch -
Sleep	Sleep	Down	Down
Mute	Mute	Right	Right
1	1	Left	Left
2	2	Vol-	Vol -
3	3	Vol+	Vol +
4	4	Enter	Ok
5	5	Red	Red
6	6	Green	Green
7	7	Yellow	Yellow
8	8	Blue	Blue
9	9	Info	Info
0	0	EPG	Guide
-/--	Shift + Guide	Menu	Menu
Recall	Pre Ch	Nicam	Media
Up	Up	FAV+	>>





Original		Sustituto	
FAV-	FAV-	<<	<<
TXT	TXT	REPEAT TEXT	Text
EDITOR/GROUP	Edit/Group	SETTINGS OPT	Options
INDEX	Index	RETURN BACK	Back
LANG/AUDIO	Lang/Audio	SOUND DUAL	Dual
TV/RADIO	TV/Radio	SEARCH TV/R	TV/R
SUBTITLE	Subtitle	AD SUBT	Subt
SUBPAGE	Subpage	SHIFT + AD SUBT	Shift + Subt
SIZE	Size	PICTURE FORMAT	Format
HOLD	Hold	ECO 3D	3D
STILL	Still	CLEAR EXIT	Exit
P.MODE	P.Mode	SHIFT + PICTURE FORMAT	Shift + Format
S.MODE	S.Mode	SHIFT + SOUND DUAL	Shift + Dual

Original	Sustituto

