








Original	Sustituto
Power	Power
Prog	TV/Radio /
Subtitle	Subtitle / EQ
Open/Close	Eject / Surround
OSD	Display / Media
PBC	D.Menu / Top
A-B	Yellow / YouTube / Repeat
Repeat	Green / APP / Repeat
3D	Shift + Zoom /
Random	Blue / Prime Video / Random
Slow	Shift + Play /
Clear	Exit / Cancel / Clear
Resume	Sound / Title
Digest	Shift + Subtitle / EQ
Video	Shift + 4
Zoom	Zoom / Size
Setup	Setup / OPT /

Original	Sustituto
Return	Back / Return
Up	Up
Left	Left
Enter	OK
Right	Right
Angle	Info / Angle
Down	Down
Language	Audio / Lang I/II
N/P	Picture / Format
Mute	Mute / Dimmer
Vol+	Vol+
R/L	Smart / List
Title	Shift + Sound / Title
Menu	Menu / Home
Vol-	Vol-
Reset	Sleep / Timer
1	1





Original	Sustituto
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 10+	 Guide / EPG / -/--
 Goto	 Text / Goto
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze

Original	Sustituto
 Stop	 Stop / Hold
 Step	 Shift + Pause / Step /

