




















Original	Sustituto
	Power
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Menu / Home
	Back / Return
	Up
	Left
	OK
	Right
	Down
	AV / Input / RDS
	D.Menu / Top
	Info / Angle
	Guide / EPG / -/--
	Vol+

Original	Sustituto
	Mute / Dimmer
	CH+ / Page+
	Vol-
	CH- / Page-
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Shift + Fav / Marker / PC
	0
	Fav / Marker / PC
	Picture / Format



