



Original	Sustituto
Power	Power
Mute	Mute / Dimmer
PIP-	Shift + CH- /
PIP	Zoom / Size
PIP+	Shift + CH+ /
Wide	Picture / Format
Swap	Smart / List
Lang(AD)	Audio / Lang I/II
Timers	Sleep / Timer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

Original	Sustituto
9	9
Text	Text / Goto
0	0
AV	AV / Input / RDS
i	Info / Angle
Vol+	Vol+
Tv/Radio	TV/Radio /
PR+	CH+ / Page+
Vol-	Vol-
FAV	Fav / Marker / PC
PR-	CH- / Page-
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Guide	Guide / EPG / -/--
Up	Up





	Original	Sustituto	Original	Sustituto
	Exit	Exit / Cancel / Clear		
	Left	Left		
	OK	OK		
	Right	Right		
	Menu	Menu / Home		
	Down	Down		
	Back/P<P	Back / Return		
	Subtitle	Subtitle / EQ		
	<<	<< / Tune-		
	Play	Play / Slow		
	>>	>> / Tune+		
	LIB	Setup / OPT /		
	Stop	Stop / Hold		
	Pause	Pause / Step / Freeze		
	Rec	Rec / Rec Mode		

