





































| Original   | Sustituto  |
|--|--|
|  Power    |  Power              |
|  1        |  1                  |
|  2        |  2                  |
|  3        |  3                  |
|  4        |  4                  |
|  5        |  5                  |
|  6        |  6                  |
|  7        |  7                  |
|  8        |  8                  |
|  9        |  9                  |
|  Lang    |  Audio / Lang I/II |
|  0      |  0                |
|  [≡]... |  Subtitle / EQ    |
|  Home   |  Shift + Menu /   |
|  Home   |  D.Menu / Top     |
|  V+     |  Vol+             |
|  Mute   |  Mute / Dimmer    |

| Original  | Sustituto  |
|---|--|
|  P+        |  CH+ / Page+                  |
|  V-        |  Vol-                         |
|  Source    |  AV / Input / RDS             |
|  P-        |  CH- / Page-                  |
|  [G]       |  Guide / EPG / -/-            |
|  i         |  Info / Angle                 |
|  Up        |  Up                           |
|  Left      |  Left                         |
|  OK        |  OK                           |
|  Right     |  Right                        |
|  ←        |  Back / Return               |
|  Down    |  Down                       |
|  Exit    |  Exit / Cancel / Clear      |
|  Netflix |  Shift + Red / Netflix /    |
|  YouTube |  Shift + Yellow / YouTube / |
|  Menu    |  Menu / Home                |
|  *1      |  Picture / Format           |



