







































Original	Sustituto
 Open/Close	 Eject / Surround
 Setup	 Setup / OPT /
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 OSC	 Fav / Marker / PC
 0	 0
 Clear	 Exit / Cancel / Clear
 MC	 Guide / EPG / -/--
 Up	 Up

Original	Sustituto
 Pop Up Menu	 Menu / Home
 Left	 Left
 OK	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down
 Top Menu	 D.Menu / Top
 A-B	 Shift + Yellow / YouTube /
 Repeat	 Shift + Green / APP /
 Goto	 Text / Goto
 Display	 Display / Media
 <</<<	 << / Tune-
 Play/Pause	 Play / Slow
 >>/ >>	 >> / Tune+
 I<<	 I<< / Preset-
 Stop	 Stop / Hold
 I> I>	 Pause / Step / Freeze





Original	Sustituto	Original	Sustituto
 >>	 >> / Preset+		
 Red/Program	 Red / Netflix / Search		
 Green/Digest	 Green / APP / Repeat		
 Yellow/Zoom	 Yellow / YouTube / Repeat		
 Blue/Bookmark	 Blue / Prime Video / Random		
 Subtitle	 Subtitle / EQ		
 Audio	 Audio / Lang I/II		
 PIP	 Zoom / Size		
 PIP Audio	 Sound / Title		
 Angle	 Info / Angle		
 Connected	 Smart / List		

