










| Original | Sustituto |
|---|---|
|  Power |  Power |
|  Up / P+ |  Up |
|  Up / P+ |  CH+ / Page+ |
|  Menu |  Menu / Home |
|  Left |  Left |
|  Right |  Right |
|  Down / P- |  Down |
|  Down / P- |  CH- / Page- |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |

| Original | Sustituto |
|--|---|
|  -- |  Guide / EPG / -/-- |
|  0 |  0 |
|  P < P |  Fav / Marker / PC |
|  PP |  Back / Return |
|  Vol+ |  Vol+ |
|  I-II |  Audio / Lang I/II |
|  Mute |  Mute / Dimmer |
|  Vol- |  Vol- |
|  Info |  Info / Angle |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  [TV] |  Shift + 1 |
|  [TV] |  TV/Radio / |
|  [AV] |  AV / Input / RDS |
|  [≡] |  Text / Goto |









































































| Original | Sustituto |
|-----------|-------------|
| Power | Power |
| Up / P+ | Up |
| Up / P+ | CH+ / Page+ |
| Menu | Menu / Home |
| Left | Left |
| Select | OK |
| Right | Right |
| Down / P- | CH- / Page- |
| Down / P- | Down |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |

| Original | Sustituto |
|------------|-----------------------------|
| 9 | 9 |
| +10 | Guide / EPG / -/- |
| 0 | 0 |
| Repeat | Green / APP / Repeat |
| Search | Red / Netflix / Search |
| A→B | Yellow / YouTube / Repeat |
| Display | Display / Media |
| Audio | Audio / Lang I/II |
| Subtitle | Subtitle / EQ |
| Zoom | Zoom / Size |
| Prog | TV/Radio / |
| C | Blue / Prime Video / Random |
| Angle | Info / Angle |
| Return | Back / Return |
| Time | Sleep / Timer |
| << / Tune- | << / Tune- |
| >> / Tune+ | >> / Tune+ |





| Original | Sustituto | Original | Sustituto |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute / Dimmer | Menu Down |  Down |
| Txt Stop |  Stop / Hold | Back |  Back / Return |
| Tone+ |  >> / Tune+ | Volume+ |  Vol+ |
| Lang |  Sound / Title | Chan.Up |  CH+ / Page+ |
| Menu audio |  Audio / Lang I/II | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | Display |  Display / Media |
| Txt Expand |  Zoom / Size | Chan.Down |  CH- / Page- |
| Sleep Timer |  Sleep / Timer | 1 |  1 |
| Return TV |  TV/Radio / | 2 |  2 |
| Menu video |  D.Menu / Top | 3 |  3 |
| Text |  Text / Goto | 4 |  4 |
| Menu |  Menu / Home | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Info |  Info / Angle | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  OK | 9 |  9 |

| Original | Sustituto | Original | Sustituto |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute / Dimmer | Menu Down |  Down |
| Txt Stop |  Stop / Hold | Back |  Back / Return |
| Tone+ |  >> / Tune+ | Volume+ |  Vol+ |
| Lang |  Sound / Title | Chan.Up |  CH+ / Page+ |
| Menu audio |  Audio / Lang I/II | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | Display |  Display / Media |
| Txt Expand |  Zoom / Size | Chan.Down |  CH- / Page- |
| Sleep Timer |  Sleep / Timer | 1 |  1 |
| Return TV |  TV/Radio / | 2 |  2 |
| Menu video |  D.Menu / Top | 3 |  3 |
| Text |  Text / Goto | 4 |  4 |
| Menu |  Menu / Home | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Info |  Info / Angle | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  OK | 9 |  9 |



