





































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	Movie		1
	Photo		2
	Music		3
	Browser		Media
	Setup		Options
	Info		Info
	Home		Smart
	Return		Back
	Vol+		Vol +
	Vol-		Vol -
	>>/FF		>>
	<</FR		<<
	>>I/Next		>>I
	I<</Prev		I<<
	Pause		Pause
	Play		Play
	Stop		Stop
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Goto		Pre Ch
	Repeat		Text
	Audio		Dual
	Rotate		Sleep
	Zoom		Eject
	Sub-T		Subt
	16:9		Format
	AV		AV
	HDMI		TV/R

