




















































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	Rec		Rec / Rec Mode
	TV Sys.		D.Menu / Top
	Browser		Display / Media
	Copy		Picture / Format
	Music		Smart / List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Repeat		Shift + Green / APP / Repeat

Original	Sustituto	Original	Sustituto
	0		0
	Info		Info / Angle
	<<		<< / Tune-
	Vol -		Vol-
	Vol +		Vol+
	I<<		I<< / Preset-
	>>		>> / Tune+
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	>>I		>>I / Preset+
	Home		Shift + Menu / Home
	Up		Up
	Return		Back / Return
	Left		Left
	Enter		OK
	Right		Right





Original	Sustituto
 Menu	 Menu / Home
 Down	 Down
 Setup	 Setup / OPT /
 Time Shift	 Sleep / Timer
 Slow I>	 Shift + Play /
 A-B	 Shift + YouTube /
 Goto	 Shift + Text /
 Zoom	 Zoom / Size
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Angle	 Shift + Info / Angle
 Red	 Red / Netflix / Search
 Green / EPG	 Green / APP / Repeat
 Green / EPG	 Guide / EPG / -/--
 Yellow / Text	 Text / Goto
 Yellow / Text	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random

Original	Sustituto

