





































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back
 Text	 Text
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Sleep	 Sleep

Original	Sustituto
 Audio	 Dual
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Source	 AV
 Display	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Menu	 Menu





Original		Sustituto		Original		Sustituto	
	Exit		Exit		Timeshift		Options
	Subtitle		Subt		Tv/Radio		TV/R
	Index		List				
	Size		Format				
	Reveal		D. Menu				
	Play/Hold		Play				
	Pause		Pause				
	I<</Cancel		I<<				
	>>I/Subpage		>>I				
	Stop		Stop				
	Rec		Rec				
	FAV		Pre Ch				
	<</FAV-		<<				
	>>/FAV+		>>				
	Mix		Smart				
	EPG		Guide				
	Media		Media				

