







































































| Original  |          | Rechange  |                       | Original  |           | Rechange  |                       |
|---|----------|---|-----------------------|---|-----------|---|-----------------------|
|    | Power    |    | Power                 |    | Index     |    | D.Menu / Top          |
|    | Mute     |    | Mute / Dimmer         |    | Reveal    |    | Setup / OPT /         |
|    | Play     |    | Play / Slow           |    | Text      |    | Text / Goto           |
|    | Pause    |    | Pause / Step / Freeze |    | AV/Source |    | AV / Input / RDS      |
|    | Stop     |    | Stop / Hold           |    | Menu      |    | Menu / Home           |
|    | Rec      |    | Rec / Rec Mode        |    | Up        |    | Up                    |
|    | <<       |    | << / Tune-            |    | i/Info    |    | Info / Angle          |
|    | >>       |    | >> / Tune+            |    | Left      |    | Left                  |
|    | I<<      |    | I<< / Preset-         |    | OK        |    | OK                    |
|   | >>I      |   | >>I / Preset+         |   | Right     |   | Right                 |
|  | S.Mode   |  | Sound / Title         |  | Exit      |  | Exit / Cancel / Clear |
|  | Audio    |  | Audio / Lang I/II     |  | Down      |  | Down                  |
|  | Subtitle |  | Subtitle / EQ         |  | Back      |  | Back / Return         |
|  | P.Mode   |  | Picture / Format      |  | Vol+      |  | Vol+                  |
|  | Size     |  | Zoom / Size           |  | Rec List  |  | Smart / List          |
|  | Sleep    |  | Sleep / Timer         |  | CH+       |  | CH+ / Page+           |
|  | Tv/Radio |  | TV/Radio /            |  | Vol-      |  | Vol-                  |





| Original |          | Rechange |                           | Original |               | Rechange |                             |
|----------|----------|----------|---------------------------|----------|---------------|----------|-----------------------------|
|          | ATV      |          | Display / Media           |          | Blue          |          | Blue / Prime Video / Random |
|          | CH-      |          | CH- / Page-               |          | Power/Display |          | Shift + Power               |
|          | 1        |          | 1                         |          | Hold          |          | Shift + Stop /              |
|          | 2        |          | 2                         |          | Aspect        |          | Shift + Picture / Format    |
|          | 3        |          | 3                         |          | USB           |          | Shift + 8                   |
|          | 4        |          | 4                         |          |               |          |                             |
|          | 5        |          | 5                         |          |               |          |                             |
|          | 6        |          | 6                         |          |               |          |                             |
|          | 7        |          | 7                         |          |               |          |                             |
|          | 8        |          | 8                         |          |               |          |                             |
|          | 9        |          | 9                         |          |               |          |                             |
|          | Tv Guide |          | Guide / EPG / -/--        |          |               |          |                             |
|          | 0        |          | 0                         |          |               |          |                             |
|          | FAV      |          | Fav / Marker / PC         |          |               |          |                             |
|          | Red      |          | Red / Netflix / Search    |          |               |          |                             |
|          | Green    |          | Green / APP / Repeat      |          |               |          |                             |
|          | Yellow   |          | Yellow / YouTube / Repeat |          |               |          |                             |

