



| Original | Recharge |
|-----------|------------------|
| Power | Power |
| Tv/Radio | TV/Radio / |
| Subtitle | Subtitle / EQ |
| * | D.Menu / Top |
| Cable | AV / Input / RDS |
| 1 | 1 |
| Live Zoom | Zoom / Size |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| List | Smart / List |
| Search | Display / Media |

| Original | Recharge |
|----------------|-------------------------|
| Guide | Guide / EPG / -/- |
| 0/Quick Access | 0 |
| Info | Info / Angle |
| Vol+ | Vol+ |
| Vol- | Vol- |
| Mute | Mute / Dimmer |
| P+ | CH+ / Page+ |
| P- | CH- / Page- |
| Home | Menu / Home |
| Back | Back / Return |
| Exit | Exit / Cancel / Clear |
| Text | Text / Goto |
| Up | Up |
| Netflix | Shift + Red / Netflix / |
| Down | Down |
| Amazon | Shift + Blue / Prime |
| Right | Right |



