








































































































| Original  | Recharge   |
|---|--|
|  Power         |  Power        |
|  Source        |  AV           |
|  Sleep         |  Sleep        |
|  Picture Mode  |  Format       |
|  Sound Mode    |  Shift + Dual |
|  1             |  1            |
|  2             |  2            |
|  3             |  3            |
|  4             |  4            |
|  5             |  5            |
|  6            |  6           |
|  7           |  7          |
|  8           |  8          |
|  9           |  9          |
|  0           |  0          |
|  [<>]/Aspect |  3D         |
|  Guide       |  Guide      |

| Original  | Recharge   |
|---|--|
|  Back    |  Back       |
|  Eco     |  Shift + 3D |
|  Menu    |  Menu       |
|  i       |  Info       |
|  Audio   |  Dual       |
|  Up      |  Up         |
|  Down    |  Down       |
|  Right   |  Right      |
|  Left    |  Left       |
|  OK      |  Ok         |
|  Vol+   |  Vol +     |
|  Vol-  |  Vol -    |
|  Mute  |  Mute     |
|  P+    |  Ch +     |
|  P-    |  Ch -     |
|  Red   |  Red      |
|  Green |  Green    |





| Original  |          | Recharge  |         | Original | Recharge |
|---|----------|---|---------|----------|----------|
|    | Yellow   |    | Yellow  |          |          |
|    | Blue     |    | Blue    |          |          |
|    | Fun-Link |    | Media   |          |          |
|    | [...]    |    | Subt    |          |          |
|    | [≡◆]     |    | D. Menu |          |          |
|    | [≡o]     |    | Smart   |          |          |
|    | [≡+]     |    | Options |          |          |
|    | [≡]      |    | Text    |          |          |
|    | [≡?]     |    | TV/R    |          |          |
|    | [≡i]     |    | List    |          |          |
|   | Play     |   | Play    |          |          |
|  | Pause    |  | Pause   |          |          |
|  | Stop     |  | Stop    |          |          |
|  | >>       |  | >>      |          |          |
|  | <<       |  | <<      |          |          |
|  | >>       |  | >>      |          |          |
|  | <<       |  | <<      |          |          |

