



Original	Recharge
Power	Power
A1	Shift + Smart / List
V-Format	Picture / Format
Timer	Sleep / Timer
Mute	Mute / Dimmer
Tms	AV / Input / RDS
B2	Shift + Display / Media
F1	Shift + 1
Tv/Sat	Smart / List
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

Original	Recharge
9	9
Tv/Radio	TV/Radio /
0/Zoom	0
0/Zoom	Zoom / Size
Recall	Back / Return
Find	Shift + Red / Netflix /
Vol-	Vol-
Page-	CH- / Page-
SAT	Display / Media
Rec	Rec / Rec Mode
Vol+	Vol+
Page+	CH+ / Page+
FAV	Fav / Marker / PC
Menu	Menu / Home
Up	Up
Info	Info / Angle
Left	Left





Original	Recharge

Original	Recharge

