



Original	Rechange
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
[=+]/-/--	GUIDE
Recall/Auto/Pre-C	PRE-CH
Mute	Mute
Vol+	Vol +
Vol-	Vol -
P+	Ch +

Original	Rechange
P-	Ch -
[=..]/Source	AV
[=i]/Menu	Menu
(+)	Media
[=?]/Info/[+]	Info
Exit	Exit
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
TTX/MIX	Text
[=o]/Dual I-II	Dual
[=◇]	Format
[=◇]/Sleep	Sleep
Red	Red
Green	Green



