























































































Original	Rechange	Original	Rechange
 Power	 Power	 Down	 Down
 PBC	 Green	 Right	 Right
 Display	 Info	 Left	 Left
 Eject	 Eject	 Play	 Play
 Subtitle	 Subt	 I<<	 I<<
 Search	 Shift + TV/R	 >>I	 >>I
 Angle	 Red	 <<	 <<
 Language	 Dual	 >>	 >>
 Setup	 Options	 All	 Text
 Title	 Back	 A-B	 Shift + Play
 Menu	 Menu	 Vol-	 Vol-
 Zoom	 Shift + Eject	 Vol+	 Vol+
 Resume	 TV/R	 Mute	 Mute
 Pause	 Pause	 +10	 Guide
 Slow	 Exit	 1	 1
 Stop	 Stop	 2	 2
 Up	 Up	 3	 3





Original	Rechange	Original	Rechange
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P.Scan		Media
	Program		Sleep

