







































































| Original | | Rechange | | Original | | Rechange | |
|---|------------|---|-------------------|---|--------------|---|-------------------|
|  | Power |  | Power |  | 9 |  | 9 |
|  | Input 1 |  | Shift + 1 |  | [+]/Timer |  | Info / Angle |
|  | Input 2 |  | Shift + 2 |  | [+]/Timer |  | Sleep / Timer |
|  | Input 3 |  | Shift + 3 |  | 0 |  | 0 |
|  | Input 4 |  | Shift + 4 |  | HDMI Control |  | Smart / List |
|  | Input 5 |  | Shift + 5 |  | P+ |  | CH+ / Page+ |
|  | PC |  | Fav / Marker / PC |  | I-II |  | Audio / Lang I/II |
|  | [+]/[≡◇] |  | Setup / OPT / |  | Vol+ |  | Vol+ |
|  | [<>] |  | Picture / Format |  | P- |  | CH- / Page- |
|  | 1 |  | 1 |  | Mute |  | Mute / Dimmer |
|  | 2 |  | 2 |  | Vol- |  | Vol- |
|  | 3 |  | 3 |  | Return |  | Back / Return |
|  | 4 |  | 4 |  | Up |  | Up |
|  | 5 |  | 5 |  | Home Menu |  | Menu / Home |
|  | 6 |  | 6 |  | Left |  | Left |
|  | 7 |  | 7 |  | Enter |  | OK |
|  | 8 |  | 8 |  | Right |  | Right |



