










Original	Rechange
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV	 TV/R
 RGB	 List
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +

Original	Rechange
 CH-	 Ch -
 Mute	 Mute
 In Stop	 D. Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right/time Shift	 Right
 Left/Time Shift	 Left
 Menu	 Menu
 Exit	 Exit
 In Start	 Eject
 ADJ	 Options
 XStudio	 Dual
 Text	 Text
 Check-P	 Shift + Left
 Check-S	 Shift + Right
 PSM	 Pre Ch





Original		Rechange	
	PIP		3D
	CAP		Info
	MPX		Sleep
	SSM		Subt
	ARC		Format
	Red/Info		Red
	Green/Still		Green
	Yellow/HDMI-HO		Yellow
	Blue/USB-HOT		Blue
	Eye		Back
	B-Tooth		Smart
	Simplink / PIP PR-		Shift + Ch -
	PIP PR +		Shift + Ch +
	Tilt/PIP Input		Shift + AV
	Play		Play
	Pause/Swap		Pause
	>>I		>>I

Original		Rechange	
	I<<		I<<
	P-Only		Guide
	AV1		Shift + 1
	AV2		Shift + 2
	AV3		Shift + 3
	COMP1		Shift + 4
	COMP2		Shift + 5
	HDMI1		Shift + 6
	HDMI2		Shift + 7
	HDMI3		Shift + 8
	HDMI4/DVI		Shift + 9

