






































| Original | Recharge | Original | Recharge |
|----------------|---|-----------------------------|-----------------------------|
| Power |  | Power | Power |
| OK |  | OK | OK |
| Up |  | Up | Up |
| Down |  | Down | Down |
| Right |  | Right | Right |
| Left |  | Left | Left |
| Back |  | Back / Return | Back / Return |
| Vol + |  | Vol+ | Vol+ |
| Vol - |  | Vol- | Vol- |
| Home / Smart |  | Menu / Home | Menu / Home |
| 3D |  | Shift + 3 | Shift + 3 |
| Mute |  | Mute / Dimmer | Mute / Dimmer |
| P + |  | CH+ / Page+ | CH+ / Page+ |
| P - |  | CH- / Page- | CH- / Page- |
| Ratio |  | Picture / Format | Picture / Format |
| List |  | Smart / List | Smart / List |
| Q.Menu |  | D.Menu / Top | D.Menu / Top |
| Subtitle |  | Subtitle / EQ | Subtitle / EQ |
| Settings |  | Setup / OPT / | Setup / OPT / |
| >> |  | >>I / Preset+ | >>I / Preset+ |
| >> |  | >> / Tune+ | >> / Tune+ |
| Play |  | Play / Slow | Play / Slow |
| AD / PIP |  | Sound / Title | Sound / Title |
| << |  | I<< / Preset- | I<< / Preset- |
| << |  | << / Tune- | << / Tune- |
| Rec |  | Rec / Rec Mode | Rec / Rec Mode |
| Pause |  | Pause / Step / Freeze | Pause / Step / Freeze |
| Text |  | Text / Goto | Text / Goto |
| FAV |  | Fav / Marker / PC | Fav / Marker / PC |
| Exit |  | Exit / Cancel / Clear | Exit / Cancel / Clear |
| Input |  | AV / Input / RDS | AV / Input / RDS |
| Blue |  | Blue / Prime Video / Random | Blue / Prime Video / Random |
| Yellow |  | Yellow / YouTube / Repeat | Yellow / YouTube / Repeat |
| Stop / Live TV |  | Stop / Hold | Stop / Hold |



| Original | Recharge | Original | Recharge |
|------------|---|---------------|---|
| AV Mode |  +  Shift + AV / Input / RDS | 5 |  5 |
| Green |  Green / APP / Repeat | Q.View |  +  Shift + Display / Media |
| Red |  Red / Netflix / Search | 4 |  4 |
| 0 |  0 | Live Zoom |  Zoom / Size |
| AD |  Audio / Lang I/II | 3 |  3 |
| TV / PC |  +  Shift + Fav / Marker / PC | 2 |  2 |
| Search |  +  Shift + Red / Netflix / | 1 |  1 |
| App |  +  Shift + Green / APP / | T.Opt |  +  Shift + Setup / OPT / Tools |
| TV / Radio |  TV/Radio / | Energy Saving |  Eject / Surround |
| Guide |  Guide / EPG / -/-- | My APPS |  +  Shift + Smart / List |
| Info |  Info / Angle | | |
| Recent |  Sleep / Timer | | |
| 9 |  9 | | |
| 8 |  8 | | |
| 7 |  7 | | |
| Live Menu |  Display / Media | | |
| 6 |  6 | | |

