







































































Original		Recharge		Original		Recharge	
	Power		Power		i		Info
	Source		AV		Vol +		Vol +
	Mute		Mute		Vol -		Vol -
	V-Format		Format		Red		Red
	Text		Text		Green		Green
	Menu		Menu		Yellow		Yellow
	Guide		Guide		Blue		Blue
	Up		Up		1		1
	Down		Down		2		2
	Right		Right		3		3
	Left		Left		4		4
	OK / List		Ok		5		5
	Exit		Exit		6		6
	Opt+		Options		7		7
	Back		Back		8		8
	P +		Ch +		9		9
	P -		Ch -		0		0



