



Original	Recharge	Original	Recharge
Power	Power	Tv Pre-CH	Back
Tv Power	Shift + Power	Dimmer	0
Source	AV	I<<	I<<
Auto Power	Sleep	Stop	Stop
Speaker	Pre Ch	Play	Play
Tv Source	Shift + AV	Pause	Pause
Repeat	Text	>>I	>>I
Any net	Media	Sound Effect	Menu
Soundshare	Dual	Smart Volume	Smart
Tv Vol+	Shift + Vol +	3D Sound Plus	3D
Tv Vol-	Shift + Vol -	DRC	Subt
Tv CH+	Ch +	Right S/W Level	Right
Tv CH-	Ch -	Left S/W Level	Left
Audio Sync+	3	Vol+	Vol +
Audio Sync-	6	Vol-	Vol -
Tv Mute	Shift + Mute	Mute	Mute
Tv Info	Info		

