



Original	Rechange
 Power	 Power
 TV / Rad	 TV/R
 Audio	 Dual
 Text	 Text
 App	 Media
 List	 List
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Menu	 Menu
 EPG	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok

Original	Rechange
 Back	 Back
 Exit	 Exit
 Vol +	 Vol +
 Vol -	 Vol -
 i	 Info
 Mute	 Mute
 Prog +	 Ch +
 Prog -	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9



