

























































Original	Recharge	Original	Recharge
	Power		Power
	SAT		AV
	Mute		Mute
	PGUP		Shift + Ch +
	PGDN		Shift + Ch -
	FAV +		Shift + Right
	FAV -		Shift + Left
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SUB		Subt
	Audio		Dual
	TV / R		TV/R
	Sleep		Sleep
	TXT		Text
	RCL		Back
	Menu		Menu
	Info		Info
	VL +		Vol +
	VL -		Vol -
	Up		Up
	Right		Right
	Down		Down





Original	Rechange
 Left	 Left
 OK	 Ok
 CH +	 Ch +
 CH -	 Ch -
 EPG	 Guide
 FAV	 Pre Ch
 <<<	 <<<
 >>>	 >>>
 PAUSE	 Pause
 I<<<	 I<<<
 >>>I	 >>>I
 Rec	 Rec
 Play / Pause	 Play
 Stop	 Stop
 USB	 Media
 MP3	 Smart
 JPEG	 Shift + Media

Original	Rechange
 PVR List	 List
 Still >I<	 Shift + Stop
 Zoom	 Eject
 Edit	 Options
 Exit	 Exit
 A-B	 Shift + Text
 T.S.	 3D
 GOTO	 D. Menu

