







































































Original	Recharge	Original	Recharge
 Standby / On	 Power	 Vol +	 Vol +
 Function	 AV	 Vol -	 Vol -
 Open / Close	 Eject	 Mute	 Mute
 Karaoke	 TV/R	 Top Menu	 Shift + Menu
 Key / Echo	 Guide	 Menu / PopUp	 Menu
 NET Contents	 Media	 Home Menu	 Smart
 YouTube	 Shift + Media	 Up	 Up
 Sleep	 Sleep	 Left	 Left
 Exit	 Exit	 Return	 Back
 Mic Vol +	 Ch +	 Enter	 Ok
 Mic Vol -	 Ch -	 Right	 Right
 Home Media	 Shift + Smart	 Down	 Down
 Dimmer	 Shift + Mute	 Resolution	 Format
 CD / SACD	 D. Menu	 Replay	 Shift + Play
 Display	 Info	 Continued	 List
 USB REC	 Rec	 Tools	 Options
 Sound	 Shift + Dual	 Skip Search	 Shift + Right





Original	Rechange
<< REV	<<
Play	Play
>> FWD	>>
I<< / <   / <	I<<
Pause	Pause
Stop	Stop
>>  /  > /   >	>>
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Rechange
Clear	Shift + Exit
Repeat	Text
Subtitle	Subt
Angle	Shift + Format
Virtual 3D Sound	3D
A-B	Shift + Text
Program / Red	Red
Program / Red	Shift + Sleep
RDS / Bookmark / Green	Green
Audio	Dual
RDS / Bookmark / Green	Pre Ch
PTY / Zoom /	Yellow
PTY / Zoom /	Shift + Eject
Index / Blue	Blue

