

























































Original	Rechange	Original	Rechange
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 FAV / SAT	 Pre Ch
 6	 6	 Sleep	 Sleep
 7	 7	 Vol -	 Vol -
 8	 8	 Vol +	 Vol +
 9	 9	 IPTV	 Smart
 0	 0	 A/V+	 AV
 Info	 Info	 Option	 Options
 Recall	 Back	 Red	 Red
 Menu	 Menu	 Green	 Green
 TV/Rad	 TV/R	 Yellow	 Yellow
 EPG	 Guide	 Blue	 Blue



