




























































Original	Recharge	Original	Recharge
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Menu Left	 Left
Update	 Smart	OK Enter	 Ok
Reveal	 Format	Menu Off	 Exit
Txt Stop	 Stop	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Chan.Up	 Ch +
Info	 Info	Chan.Down	 Ch -
Menu video	 D. Menu	Menu audio	 Dual
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Display	 Shift + Info	5	 5
Menu Up	 Up	6	 6
Menu Down	 Down	7	 7



Original	Recharge	Original	Recharge
8		8	
9		9	
0/10		0	
Guide -/-- 1.		Guide	
2.Fav P/C 2.		Pre Ch	
Red		Red	
Tone-		I<<	
Tone+		>>I	
Audio-		<<	
Color- S.Std		List	
Audio+		>>	
Green		Green	
Yellow		Yellow	
Blue		Blue	
On/Tim		Shift + Subt	
Game Coo		Shift + Eject	
Browse		Shift + Back	
Contrast+		Shift + Ch +	
Contrast-		Shift + Ch -	
Swap		Media	
Surround		Shift + Red	
On Pip		3D	
Nicam/Mono		Shift + Green	
Level L		Shift + Yellow	
Level R/Woofer		Shift + Blue	

