






































































	Original	Recharge	Original	Recharge
	Power			♪ / S.Mode
	[i+]			⦿ / P.Mode
	DTT/TV			Vol+
	AV1			Vol-
	AV2			I/II
	AV3			Mute
	AV4			P+
	AV5			P-
	RGB1			1
	RGB2			2
	Menu			3
	Back			4
	Up			5
	Down			6
	Right			7
	Left			8
	OK			9
				Shift + Dual
				Shift + Format
				Vol +
				Vol -
				Dual
				Mute
				Ch +
				Ch -
				1
				2
				3
				4
				5
				6
				7
				8
				9

































Original		Rechange		Original		Rechange	
	0		0				
	2-4-12 / [ ]		3D				
	[ ]		Options				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	[ ]		List				
	[ ]		Smart				
	[...]/Slide Show		Subt				
	[ ]/?/Rotate		Pre Ch				
	[ ]		Text				
	Swivel		Sleep				
	[ <> ]		Format				
	Photo		Media				













































	Original	Rechange	Original	Rechange
	Power			
	OK			
	Up			
	Down			
	Right			
	Left			
	Menu			
	Play			
	Stop			
	Pause			
	<<			
	>>			
	P+			
	P-			





Original		Rechange		Original		Rechange	
	Power		Power		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down				
	Right		Right				
	Left		Left				
	P+		Ch +				
	P-		Ch -				
	Vol+		Vol +				
	Vol-		Vol -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

