



| Original     | Recharge                   |
|--------------|----------------------------|
| DAT/TAPE1    | Shift + Red / Netflix /    |
| TAPE2        | Shift + Green / APP /      |
| << Deck A    | Down                       |
| << Deck B    | Shift + Down               |
| < Deck B     | Shift + Left               |
| < Deck A     | Left                       |
| > Deck B     | Shift + Right              |
| > Deck A     | Right                      |
| >> Deck B    | Shift + Up                 |
| >> Deck A    | Up                         |
| TAPE3        | Shift + Yellow / YouTube / |
| Stop Deck A  | OK                         |
| Stop Deck B  | Shift + OK                 |
| Pause Deck B | Shift + Pause / Step /     |
| Deck B Rec   | Shift + Stop /             |
| Rec Deck A   | Rec / Rec Mode             |
| Rec Deck B   | Shift + Rec / Rec Mode     |

| Original       | Recharge                  |
|----------------|---------------------------|
| AUX            | Yellow / YouTube / Repeat |
| Tuner Preset + | Shift + >>I / Preset+     |
| Tuner Preset + | CH+ / Page+               |
| CD             | Red / Netflix / Search    |
| Tuner Preset - | Shift + I<< / Preset-     |
| Tuner Preset - | CH- / Page-               |
| Tuner          | Green / APP / Repeat      |
| 1 Tuner        | 1                         |
| 2 Tuner        | 2                         |
| 3 Tuner        | 3                         |
| 4 Tuner        | 4                         |
| 5 Tuner        | 5                         |
| 6 Tuner        | 6                         |
| 7 Tuner        | 7                         |
| 8 Tuner        | 8                         |
| 9 Tuner        | 9                         |
| 0 Tuner        | 0                         |



