







































































| Original | | Rechange | | Original | | Rechange | |
|---|----------|---|--------------|---|-------|---|--------------|
|  | POWER |  | Power |  | USB |  | AV |
|  | MUTE |  | Mute |  | MENU |  | Menu |
|  | DISP |  | Shift + Info |  | EXIT |  | Exit |
|  | AUDIO |  | Dual |  | UP |  | Up |
|  | Tv/Radio |  | TV/R |  | DOWN |  | Down |
|  | SLEEP |  | Sleep |  | RIGHT |  | Right |
|  | 1 |  | 1 |  | LEFT |  | Left |
|  | 2 |  | 2 |  | OK |  | Ok |
|  | 3 |  | 3 |  | CH+ |  | Ch + |
|  | 4 |  | 4 |  | CH- |  | Ch - |
|  | 5 |  | 5 |  | VOL+ |  | Vol + |
|  | 6 |  | 6 |  | VOL- |  | Vol - |
|  | 7 |  | 7 |  | P↑ |  | Shift + Ch + |
|  | 8 |  | 8 |  | P↓ |  | Shift + Ch - |
|  | 9 |  | 9 |  | INFO |  | Info |
|  | 0 |  | 0 |  | BACK |  | Back |
|  | EPG |  | Guide |  | ZOOM |  | Eject |





| Original | Recharge | Original | Recharge |
|---|---|----------|----------|
|  RED / FIND |  Red | | |
|  GREEN |  Green | | |
|  YELLOW / MARK |  Yellow | | |
|  BLUE / JUMP |  Blue | | |
|  FAV / A - B |  Pre Ch | | |
|  SUB / SWP |  Subt | | |
|  DVR |  Media | | |
|  TXT |  Text | | |
|  SKIP PREV |  I<< | | |
|  SKIP NEXT |  >>I | | |
|  REW |  << | | |
|  FWD |  >> | | |
|  PAUSE |  Pause | | |
|  REC |  Rec | | |
|  PLAY |  Play | | |
|  STOP |  Stop | | |

