



Original	Rechange	Original	Rechange
 Power	 Power	 Up	 Up
 Source	 AV	 Left	 Left
 Rec	 Rec	 OK	 Ok
 APP	 Media	 Right	 Right
 <<	 <<	 Down	 Down
 Play / Pause	 Play	 EPG	 Guide
 Play / Pause	 Pause	 Back	 Back
 >>	 >>	 Vol+	 Vol +
 I<<	 I<<	 Vol-	 Vol -
 Stop	 Stop	 Info	 Info
 >>I	 >>I	 Mute	 Mute
 Red	 Red	 Prog+	 Ch +
 Green	 Green	 Prog-	 Ch -
 Yellow	 Yellow	 1	 1
 Blue	 Blue	 2	 2
 Menu	 Menu	 3	 3
 Exit	 Exit	 4	 4



