











































Original	Recharge
 System Power	 Power
 Clock Display	 Shift + Info
 Display	 Info
 Sleep	 Sleep
 Tape	 Red
 Tuner	 Green
 CD	 Yellow
 DAT	 Blue
 Video	 Shift + Red
 Phono	 Shift + Green
 Tuner Band	 Menu
 >12 Tuner	 3D
 >12 EQ	 Shift + 3D
 Disco	 Shift + 1
 1 Tuner	 1
 Clasic	 Shift + 3
 2 Tuner	 2

Original	Recharge
 3 Tuner	 3
 Jazz	 Shift + 4
 4 Tuner	 4
 Movie	 Shift + 5
 5 Tuner	 5
 Falt	 Shift + 6
 6 Tuner	 6
 Morning	 Shift + 7
 7 Tuner	 7
 Night	 Shift + 8
 8 Tuner	 8
 Hall	 Shift + 9
 9 Tuner	 9
 WM	 Shift + Guide
 10 Tuner	 Guide
 Car	 Shift + 0
 11 Tuner	 0





	Original	Recharge		Original	Recharge
	Normal	+	Shift + Pre Ch		
	12 Tuner		Pre Ch		
	Balance L		Left		
	Balance R		Right		
	Memory		Media		
	Pops	+	Shift + 2		
	Direct		Smart		
	Total Effect Control+		Ch +		
	Total Effect Control-		Ch -		
	Muting		Mute		
	Vol+		Vol +		
	Vol-		Vol -		





Original	Recharge
System Power	Power
Clock Display	Shift + Info
Display	Info
Sleep	Sleep
Tape	Red
Tuner	Green
CD	Yellow
DAT	Blue
Video	Shift + Red
Phono	Shift + Green
Play CD	Play
Pause CD	Pause
Stop CD	Stop
I<< CD	I<<
>>I CD	>>I
Time	AV
Repeat	Text


Original	Recharge
Continue	Format
Shuffle	TV/R
Program	Shift + Sleep
Check	Eject
Clear	Exit
> 12 CD	3D
>12 EQ	Shift + 3D
Disco	Shift + 1
1 CD	1
Pops	Shift + 2
2 CD	2
3 CD	3
Clasic	Shift + 3
Jazz	Shift + 4
4 CD	4
5 CD	5
Movie	Shift + 5





Original		Recharge		Original		Recharge	
	6 CD		6		Direct		Smart
	Falt		Shift + 6		Total Effect Control+		Ch +
	Morning		Shift + 7		Total Effect Control-		Ch -
	7 CD		7		Muting		Mute
	Night		Shift + 8		Vol+		Vol +
	8 CD		8		Vol-		Vol -
	Hall		Shift + 9				
	9 CD		9				
	WM		Shift + Guide				
	10 CD		Guide				
	Car		Shift + 0				
	11 CD		0				
	12 CD		Pre Ch				
	Normal		Shift + Pre Ch				
	Balance L		Left				
	Balance R		Right				
	Memory		Media				





Original	Recharge
System Power	Power
Clock Display	Shift + Info
Display	Info
Sleep	Sleep
Tape	Red
Tuner	Green
CD	Yellow
DAT	Blue
Video	Shift + Red
Phono	Shift + Green
<< Tape Deck	<<
< Tape Deck A	I<<
> Tape Deck A	Play
>> Tape Deck	>>
Stop Tape Deck A	Stop
Pause Tape Deck	Pause
Rec Tape Deck	Rec

Original	Recharge
>12 EQ	Shift + 3D
Disco	Shift + 1
Pops	Shift + 2
Clasic	Shift + 3
Jazz	Shift + 4
Movie	Shift + 5
Falt	Shift + 6
Morning	Shift + 7
Night	Shift + 8
Hall	Shift + 9
WM	Shift + Guide
Car	Shift + 0
Normal	Shift + Pre Ch
Balance L	Left
Balance R	Right
Memory	Media
Direct	Smart





Original	Recharge
System Power	Power
Clock Display	Shift + Info
Display	Info
Sleep	Sleep
Tape	Red
Tuner	Green
CD	Yellow
DAT	Blue
Video	Shift + Red
Phono	Shift + Green
<< Tape Deck	<<
< Tape Deck B	I<<
> Tape Deck B	Play
>> Tape Deck	>>
Stop Tape Deck B	Stop
Pause Tape Deck	Pause
Rec Tape Deck	Rec

Original	Recharge
>12 EQ	Shift + 3D
Disco	Shift + 1
Pops	Shift + 2
Clasic	Shift + 3
Jazz	Shift + 4
Movie	Shift + 5
Falt	Shift + 6
Morning	Shift + 7
Night	Shift + 8
Hall	Shift + 9
WM	Shift + Guide
Car	Shift + 0
Normal	Shift + Pre Ch
Balance L	Left
Balance R	Right
Memory	Media
Direct	Smart



