



Original	Recharge	Original	Recharge
RCVR On	Power	RCVR Test / Menu	Menu
RCVR Standby	Shift + Power	RCVR Audio	Dual
RCVR Sleep	Sleep	RCVR Level	Media
RCVR Return	Back	RCVR Level Up	Smart
RCVR Setup	Options	RCVR I<<	I<<
RCVR Disc+	Ch +	RCVR Play	Play
RCVR Disc-	Ch -	RCVR >>I	>>I
RCVR Up	Up	RCVR <<	<<
RCVR Left	Left	RCVR Stop	Stop
RCVR Enter	Ok	RCVR >>	>>
RCVR Right	Right	RCVR Rec /	Rec
RCVR Down	Down	RCVR Pause / Play Rev.	Pause
RCVR Vol+	Vol +	Open / Close	Eject
RCVR Vol-	Vol -	RCVR Input Sel.	1
RCVR Muting	Mute	RCVR Input Sel.	2
RCVR CH Sel / Top Menu	Shift + Menu	RCVR Input Sel.	3
RCVR CH Sel / Top Menu	D. Menu	RCVR Input Sel.	4





Original Recharge





































































	RCVR Input Sel.		5
	RCVR Input Sel.		6
	RCVR Input Sel.		7
	RCVR Input Sel.		8
	RCVR Input Sel.		9
	RCVR Input Sel.		0
	RCVR Stereo	+	Shift + 1
	RCVR Direct	+	Shift + 2
	RCVR DSP ▶	+	Shift + 3
	RCVR SURR	+	Shift + 4
	RCVR A.ST	+	Shift + 5
	RCVR ◀ DSP	+	Shift + 6
	RCVR SP A	+	Shift + 7
	RCVR SP B	+	Shift + 8
	RCVR Re-EQ	+	Shift + 9
	RCVR Dimmer	+	Shift + 0
	RCVR Display		Info

Original Recharge


	RCVR Display		Guide
	RCVR Zone 2		Pre Ch







Original		Rechange		Original		Rechange	
	ON		Power		Subtitle		Subt
	STDBY		Shift + Power		I<<		I<<
	Return		Back		Play		Play
	Setup		Options		>>I		>>I
	Disc+		Ch +		<<		<<
	Disc-		Ch -		Stop		Stop
	Up		Up		>>		>>
	Left		Left		Random		Text
	Enter		Ok		Pause		Pause
	Right		Right		Open / Close		Eject
	Down		Down		1		1
	Vol+		Vol +		2		2
	Vol-		Vol -		3		3
	Muting		Mute		4		4
	Top Menu		D. Menu		5		5
	Menu		Menu		6		6
	Angle		Format		7		7
























































	Original	Recharge	Original	Recharge
	8			8
	9			9
	0			0
	+10			Guide
	Search			TV/R





Original		Rechange		Original		Rechange	
	ON		Power		3		3
	STDBY		Shift + Power		4		4
	Disc+		Ch +		5		5
	Vol+		Vol +		6		6
	Vol-		Vol -		7		7
	Muting		Mute		8		8
	I<<		I<<		9		9
	Play		Play		0		0
	>>I		>>I		+10		Guide
	<<		<<				
	Stop		Stop				
	>>		>>				
	Random		Text				
	Pause		Pause				
	Open / Close		Eject				
	1		1				
	2		2				





Original		Rechange		Original		Rechange	
	ON		Power		3		3
	STDBY		Shift + Power		4		4
	Vol+		Vol +		5		5
	Vol-		Vol -		6		6
	Muting		Mute		7		7
	I<<		I<<		8		8
	Play		Play		9		9
	>>I		>>I		0		0
	<<		<<		+10		Guide
	Stop		Stop		Enter		Pre Ch
	>>		>>		Enter		Ok
	Rec / Random		Text				
	Rec / Random		Rec				
	Pause		Pause				
	Open / Close		Eject				
	1		1				
	2		2				

