







































































Original		Rechange		Original		Rechange	
	Power		Power		Left		Left
	Mute		Mute / Dimmer		OK		OK
	1		1		Right		Right
	2		2		List		Smart / List
	3		3		Down		Down
	4		4		Back		Back / Return
	5		5		NETFLIX		Shift + Red / Netflix /
	6		6		YouTube		Shift + Yellow / YouTube /
	7		7		prime video		Shift + Blue / Prime
	8		8		Google Play		Shift + Green / APP /
	9		9		Vol+		Vol+
	Info		Info / Angle		Google Assistant		Display / Media
	0		0		P+		CH+ / Page+
	EPG		Guide / EPG / -/--		Vol-		Vol-
	Settings		Setup / OPT /		Home		Menu / Home
	Up		Up		P-		CH- / Page-
	Input		AV / Input / RDS		Text		Text / Goto





Original		Recharge	
USB	USB	+ <b>8</b>	Shift + 8
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II
SUBT	Subt	EQ SUBTITLE	Subtitle / EQ
Play	Play / Text Mix	SLOW	Play / Slow
Pause	Pause	STEP-FREEZE 	Pause / Step / Freeze
Stop	Stop / Text Hold	HOLD	Stop / Hold
Text Size	Text Size	SIZE ZOOM	Zoom / Size
<<	<< / Text	TUNE-	<< / Tune-
I<<	I<< / Text Index	PRESET-	I<< / Preset-
>>I	>>I / Text Reveal	PRESET+	>>I / Preset+
>>	>> / Text Cancel	TUNE+	>> / Tune+
Red	Red	NETFLIX SEARCH	Red / Netflix / Search
Green	Green	APP REPEAT	Green / APP / Repeat
Yellow	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
Blue	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original		Recharge	

