



| Original             | Rechange      | Original   | Rechange      |
|----------------------|---------------|------------|---------------|
| On/Standby           | Power         | Volume+ Tv | Shift + Vol + |
| Standard             | Red           | Volume- Tv | Shift + Vol - |
| Cinema/Game          | Green         |            |               |
| Sport                | Yellow        |            |               |
| News                 | Blue          |            |               |
| Volume+              | Vol +         |            |               |
| Volume-              | Vol -         |            |               |
| Mute                 | Mute          |            |               |
| Subwoofer Level      | Ch +          |            |               |
| Subwoofer Level Down | Ch -          |            |               |
| Bass/Treble          | Dual          |            |               |
| Dimmer               | Media         |            |               |
| Line                 | Info          |            |               |
| On/Standby Tv        | Shift + Power |            |               |
| Input Tv             | AV            |            |               |
| Channel Up Tv        | Shift + Ch +  |            |               |
| Channel Down         | Shift + Ch -  |            |               |



Tv