









	Original	Rechange	Original	Rechange
	Power			Exit
	Mute			Up
	1			Down
	2			Right
	3			Left
	4			Ok
	5			Vol +
	6			Vol -
	7			Shift + Dual
	8			Format
	9			Ch +
	0			Ch -
	Audio			Sleep
	Recall			Aspect
	Tv Menu			Options
	Source			Media
	CH List			Text





	Original	Rechange		Original	Rechange
	EPG	 Guide		I<<	 I<<
	FAV	 Pre Ch		>>I	 >>I
	Info	 Info		Play	 Play
	Red	 Red		Pause	 Pause
	Green	 Green		Stop	 Stop
	Yellow	 Yellow		Rec/Rep	 Rec
	Blue	 Blue			
	DTV	 TV/R			
	Hold	 Eject			
	List	 Shift + List			
	Subpage	 Shift + Subt			
	Index	 Smart			
	PVR List	 D. Menu			
	Mix	 Shift + 3D			
	Subtitle	 Subt			
	<<	 <<			
	>>	 >>			

