
































































Original		Rechange		Original		Rechange	
	Power		Power		FAV		Fav / Marker / PC
	Display		Display / Media		Vol+		Vol+
	Guide		Guide / EPG / -/--		CH+		CH+ / Page+
	Source		AV / Input / RDS		Vol-		Vol-
	Wide		Picture / Format		CH-		CH- / Page-
	MPX		Setup / OPT /		1		1
	Menu		Menu / Home		2		2
	Up		Up		3		3
	Back / Cancel		Back / Return		4		4
	Back / Cancel		Exit / Cancel / Clear		5		5
	Left / <<		Left		6		6
	Left / <<		<< / Tune-		7		7
	OK		OK		8		8
	Right / >>		Right		9		9
	Right / >>		>> / Tune+		Teletext		Text / Goto
	Mute		Mute / Dimmer		0		0
	Down		Down		Subtitle		Subtitle / EQ





Original	Recharge	Original	Recharge
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 Index / I<<	 I<< / Preset-		
 Index / I<<	 Info / Angle		
 Size / Rec/Stop	 Rec / Rec Mode		
 Size / Rec/Stop	 Stop / Hold		
 Size / Rec/Stop	 Zoom / Size		
 Hold / Play/Pause	 Shift + Stop /		
 Hold / Play/Pause	 Play / Slow		
 Hold / Play/Pause	 Pause / Step / Freeze		
 Reveal / >>I	 >>I / Preset+		
 Reveal / >>I	 Smart / List		

