







































































Original	Recharge	Original	Recharge
 Power	 Power	 Title	 Media
 Open/Close	 Eject	 (.....)	 TV/R
 Mute	 Mute	 Exit	 Exit
 1	 1	 >>	 >>
 2	 2	 <<	 <<
 3	 3	 Play	 Play
 4	 4	 OK	 Ok
 5	 5	 >	 Right
 6	 6	 <	 Left
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 >>	 >>
 0	 0	 <<	 <<
 Audio	 Dual	 Stop	 Stop
 (.....)	 Subt	 Repeat	 Text
 Movie	 Smart	 Pause	 Pause
 Menu	 Menu	 Index	 List

