









































|   | Original | Recharge  |        | Original  | Recharge     |
|---|----------|---|--------|---|--------------|
|    | Power    |    | Power  |    | EPG          |
|    | Mute     |    | Mute   |    | Menu         |
|    | Format   |    | Format |    | Info         |
|    | SAT      |    | Smart  |    | Up           |
|    | TV/STB   |    | Media  |    | Down         |
|    | TV/Radio |    | TV/R   |    | Right        |
|    | 1        |    | 1      |    | Left         |
|    | 2        |    | 2      |    | OK           |
|    | 3        |    | 3      |    | Vol+         |
|    | 4        |    | 4      |    | Vol-         |
|  | 5        |  | 5      |  | Exit         |
|  | 6        |  | 6      |  | CH+ / >> I   |
|  | 7        |  | 7      |  | CH- / I <<   |
|  | 8        |  | 8      |  | Red/Text     |
|  | 9        |  | 9      |  | Green/Audio  |
|  | 0        |  | 0      |  | Yellow/Sub.T |
|  | Back     |  | Back   |  | Blue/Find    |

|   |        |   |      |   |       |
|---|--------|---|------|---|-------|
|    | Guide  |    | Menu |    | Info  |
|    | Up     |    | Down |    | Right |
|    | Left   |    | Ok   |    | Vol + |
|    | Vol -  |  | Exit |  | Ch +  |
|  | Ch -   |  | Red  |  | Green |
|  | Yellow |  | Blue |   |       |





|   | Original | Recharge  | Original | Recharge |
|---|----------|---|----------|----------|
|    | Edit     |  3D      |          |          |
|    | OPT      |  Options |          |          |
|    | USB/PVR  |  AV      |          |          |
|    | FAV      |  Pre Ch  |          |          |
|    | <<       |  <<      |          |          |
|    | Play     |  Play    |          |          |
|    | Pause    |  Pause   |          |          |
|    | >>       |  >>      |          |          |
|    | Stop     |  Stop    |          |          |
|   | Pg Down  |  I<<    |          |          |
|  | Pg Up    |  >>I   |          |          |
|  | Rec      |  Rec   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |
|   |          |   |          |          |

