







































































Original		Rechange		Original		Rechange	
	Standby / On		Power		USB Rec		Rec
	Function		List		Display		Info
	Open / Close		Eject		Vol+		Vol +
	Home Media		Media		Vol-		Vol -
	Karaoke		Guide		Mute		Mute
	Mic Vol+		Ch +		Top Menu		D. Menu
	Mic Vol-		Ch -		Menu / PopUp		Menu
	Resolution		Format		Up		Up
	Net Contents		Shift + Media		Left		Left
	Key Lock		Pre Ch		Enter		Ok
	Dimmer		Shift + Mute		Right		Right
	Sleep		Sleep		Down		Down
	Exit		Exit		Home Menu		Smart
	Virtual 3D Sound		3D		Return		Back
	Sound		Dual		Tools		Options
	Sound Retriever		Shift + Dual		Continued		Shift + Play
	CD/SACD		AV		Skip Search		Shift + Right





Original	Rechange
REV	<<
Play	Play
FWD	>>
I<< / <   / <	I<<
Pause	
Stop	■
>>  /  > /   >	>>
Audio	TV/R
Subtitle	Subt
Angle	Shift + Format
Repeat	Text
A-B	Shift + Text
1	1
2	2
3	3
4	4
5	5

Original	Rechange
6	6
7	7
8	8
9	9
0	0
Clear	Shift + Exit
Program / Red	Red
Program / Red	Shift + Sleep
RDS / Bookmark / Green	Green
PTY / Zoom /	Yellow
PTY / Zoom /	Shift + Eject
Index / Blue	Blue

