





















| | Original | Rechange | | Rechange |
|---|----------|---|-------|----------|
|  | Phono |  | 1 | |
|  | CD |  | 2 | |
|  | Tuner |  | 3 | |
|  | Aux |  | 4 | |
|  | Tape1 |  | 5 | |
|  | Tape2 |  | 6 | |
|  | Vol+ |  | Vol + | |
|  | Vol- |  | Vol - | |
|  | Mute |  | Mute | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

| Original | Rechange |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

