







































































Original	Recharge	Original	Recharge
 Power	 Power	 Up	 Up
 Mute	 Mute	 Left	 Left
 Recall	 Back	 OK	 Ok
 EPG	 Guide	 Right	 Right
 Info	 Info	 Down	 Down
 1	 1	 PAL / NTSC	 Format
 2	 2	 FAV	 Pre Ch
 3	 3	 TV / Radio	 TV/R
 4	 4	 SAT	 Smart
 5	 5	 TV / AV	 AV
 6	 6	 Play / Pause	 Play
 7	 7	 Play / Pause	 Pause
 8	 8	 Zoom	 Eject
 9	 9	 Red / Audio	 Red
 0	 0	 Red / Audio	 Dual
 Menu	 Menu	 Green / Position	 Green
 Exit	 Exit	 Yellow / Text	 Yellow

Original	Recharge	Original	Recharge
 Power	 Power	 Up	 Up
 Mute	 Mute	 Left	 Left
 Recall	 Back	 OK	 Ok
 EPG	 Guide	 Right	 Right
 Info	 Info	 Down	 Down
 1	 1	 PAL / NTSC	 Format
 2	 2	 FAV	 Pre Ch
 3	 3	 TV / Radio	 TV/R
 4	 4	 SAT	 Smart
 5	 5	 TV / AV	 AV
 6	 6	 Play / Pause	 Play
 7	 7	 Play / Pause	 Pause
 8	 8	 Zoom	 Eject
 9	 9	 Red / Audio	 Red
 0	 0	 Red / Audio	 Dual
 Menu	 Menu	 Green / Position	 Green
 Exit	 Exit	 Yellow / Text	 Yellow





Original	Recharge	Original	Recharge
Power		Power	
Mute		Mute	
TV / AV		AV	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Recall		Back	
SAT		Smart	
Menu		Menu	
EPG		Guide	

Original	Recharge	Original	Recharge
Info		Info	
Exit		Exit	
Up		Up	
Left		Left	
OK		Ok	
Right		Right	
Down		Down	
Vol+		Vol +	
Vol-		Vol -	
Page+		Ch +	
Page-		Ch -	
Red / Audio		Red	
Red / Audio		Dual	
Green / 		Green	
Yellow / Text		Yellow	
Yellow / Text		Text	
Blue / Find		Blue	