





































































Original		Rechange		Original		Rechange	
	Power		Power		Right		Right
	1		1		Left		Left
	2		2		Enter/OK		Ok
	3		3		I<<		I<<
	4		4		>>I		>>I
	5		5		Play		Play
	6		6		Stop		Stop
	7		7		Pause		Pause
	8		8		Subtitle		Subt
	9		9		Audio		Dual
	0		0		Zoom		Eject
	Menu		Menu		Angle		Red
	Top		Back		Repeat		Text
	On Screen		Info		A-B		Green
	Setup		Options		Scan		Media
	Up		Up		Mute		Mute
	Down		Down				

