







































































Original		Rechange		Original		Rechange	
	Power		Power		C		Pre Ch
	Mute		Mute		[*]		TV/R
	[]		Smart		[↔*]		Subt
	[≡]		Text		[↑*]		List
	Input		AV		[↑]		Options
	Output		Media		Red		Red
	1		1		Green		Green
	2		2		Yellow		Yellow
	3		3		Blue		Blue
	4		4		[≡+]		3D
	5		5		[+]		Info
	6		6		SAT		Back
	7		7		Prog+		Ch +
	8		8		Prog-		Ch -
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	-/--		Guide		Picture		Format









Original	Recharge	Original	Recharge
	Dual		
	Left		
Up/+	Up		
Down/-	Down		
Menu	Menu		
OK	Ok		
Power MDP	+ Shift + Power		
>> MDT	>>		
Play MDT	Play		
<< MDT	<<		
Stop MDT	Stop		
Pause MDT	Pause		
Prog+ MDT	+ Shift + Ch +		
Prog- MDT	+ Shift + Ch -		























	Original	Rechange	Original	Rechange
	Power			
	Prog+			
	Prog-			
	>>			
	Play			
	<<			
	Stop			
	Pause			
	Rec			






















Original	Recharge	Original	Recharge
 Power	 Power		
 Prog+	 Ch +		
 Prog-	 Ch -		
 >>	 >>		
 Play	 Play		
 <<	 <<		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		





	Original	Recharge	Original	Recharge
	Power			
	Prog+			
	Prog-			
	>>			
	Play			
	<<			
	Stop			
	Pause			
	Rec	