






Original		Recharge		Original		Recharge	
	Standby		Power		Down / Volume-		Vol-
	1		1		Down / Volume-		Down
	2		2		Play		Play / Slow
	3		3		Pause		Pause / Step / Freeze
	4		4		Stop		Stop / Hold
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Up / Volume+		Up				
	Up / Volume+		Vol+				
	Left / Track-		I<< / Preset-				
	Left / Track-		Left				
	Right / Track+		>>I / Preset+				
	Right / Track+		Right				

