










































































































Original	Recharge	Original	Recharge
 Power	 Power	 PR-	 CH / Page-
 Green/Timer/List	 Green / APP / Repeat	 1	 1
 Yellow/Info	 Yellow / YouTube / Repeat	 2	 2
 Blue/[[^]]	 Blue / Prime Video / Random	 3	 3
 Red/[o]	 Red / Netflix / Search	 4	 4
 Up	 Up	 5	 5
 Violet/Text	 Text / Goto	 6	 6
 Left	 Left	 7	 7
 OK	 OK	 8	 8
 Right	 Right	 9	 9
 Exit	 Exit / Cancel / Clear	 AV	 AV / Input / RDS
 Menu	 Menu / Home	 0/--	 0
 Vol+	 Vol+		
 Down	 Down		
 PR+	 CH+ / Page+		
 Mute	 Mute / Dimmer		
 Vol-	 Vol-		

Original	Recharge	Original	Recharge
 PR-	 CH / Page-	 CH / Page-	 CH / Page-
 1	 1	 1	 1
 2	 2	 2	 2
 3	 3	 3	 3
 4	 4	 4	 4
 5	 5	 5	 5
 6	 6	 6	 6
 7	 7	 7	 7
 8	 8	 8	 8
 9	 9	 9	 9
 AV	 AV / Input / RDS	 AV	 AV
 0/--	 0	 0/--	 0

