



| Original  | Recharge  | Original  | Recharge  |
|---|---|---|---|
|  Power             |  Power                       |  Pause / Timeshift |  Pause / Step / Freeze |
|  Mute              |  Mute / Dimmer               |  Stop              |  Stop / Hold           |
|  Red / Zoom        |  Red / Netflix / Search      |  Rec               |  Rec / Rec Mode        |
|  Red / Zoom        |  Zoom / Size                 |  Menu              |  Menu / Home           |
|  Green / Aspect    |  Green / APP / Repeat        |  Up / CH+          |  Up                    |
|  Green / Aspect    |  Setup / OPT /               |  Exit              |  Exit / Cancel / Clear |
|  Yellow / V-Format |  Picture / Format            |  Left / Vol-       |  Left                  |
|  Yellow / V-Format |  Yellow / YouTube / Repeat   |  OK                |  OK                    |
|  Blue / Timer      |  Blue / Prime Video / Random |  Right / Vol+      |  Right                 |
|  Blue / Timer     |  Sleep / Timer              |  Info             |  Info / Angle         |
|  TTX             |  Text / Goto               |  Down / Ch-      |  Down                |
|  Fav             |  Fav / Marker / PC         |  EPG             |  Guide / EPG / -/--  |
|  <<<             |  <<< / Tune-               |  V+              |  Vol+                |
|  >>>             |  >>> / Tune+               |  PG+             |  Shift + CH+ /       |
|  I<<<            |  I<<< / Preset-            |  P+              |  CH+ / Page+         |
|  >>>I            |  >>>I / Preset+            |  V-              |  Vol-                |
|  Play            |  Play / Slow               |  PG-             |  Shift + CH- /       |

Page-





| Original |          | Recharge |               | Original | Recharge |
|----------|----------|----------|---------------|----------|----------|
|          | P-       |          | CH- / Page-   |          |          |
|          | 1        |          | 1             |          |          |
|          | 2        |          | 2             |          |          |
|          | 3        |          | 3             |          |          |
|          | 4        |          | 4             |          |          |
|          | 5        |          | 5             |          |          |
|          | 6        |          | 6             |          |          |
|          | 7        |          | 7             |          |          |
|          | 8        |          | 8             |          |          |
|          | 9        |          | 9             |          |          |
|          | TV/Radio |          | TV/Radio /    |          |          |
|          | 0        |          | 0             |          |          |
|          | Recall   |          | Back / Return |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |
|          |          |          |               |          |          |

