






































































Original		Rechange		Original		Rechange	
	Standby		Power		Source		AV / Input / RDS
	Mute		Mute / Dimmer		Menu		Menu / Home
	Play / Size		Play / Slow		Up		Up
	Pause /		Pause / Step / Freeze		Left		Left
	Stop / Hold		Stop / Hold		OK		OK
	<<		<< / Tune-		Right		Right
	>>		>> / Tune+		Exit		Exit / Cancel / Clear
	I<<		I<< / Preset-		Down		Down
	>>I		>>I / Preset+		Recall		Back / Return
	S.Mode		Sound / Title		Vol+		Vol+
	Audio		Audio / Lang I/II		CH. List		Smart / List
	Subtitle		Subtitle / EQ		CH+		CH+ / Page+
	Pic. Mode		Picture / Format		Vol-		Vol-
	Sleep		Sleep / Timer		Display		Display / Media
	TV / Radio		TV/Radio /		CH-		CH- / Page-
	Index		D.Menu / Top		1		1
	Text		Text / Goto		2		2





	Original	Recharge	Original	Recharge
		3		3
		4		4
		5		5
		6		6
		7		7
		8		8
		9		9
		0		0
		FAV		Fav / Marker / PC
		Red		Red / Netflix / Search
		Green		Green / APP / Repeat
		Yellow		Yellow / YouTube / Repeat
		Blue		Blue / Prime Video / Random
		Aspect	+	Shift + Picture / Format
		Home	+	Shift + Menu /
		Reveal	+	Shift + Back / Return
		Mouse	+	Shift + Smart / List
				IE
			+	Shift + Display / Media

