



Original	Recharge
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Text	Text / Goto
0	0
Recall	Back / Return
P.Mode	Picture / Format
S.Mode	Sound / Title
Audio	Audio / Lang I/II

Original	Recharge
Sleep	Sleep / Timer
Source	AV / Input / RDS
CH+	CH+ / Page+
Vol+	Vol+
Display	Display / Media
CH-	CH- / Page-
Vol-	Vol-
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Up	Up
Down	Down
Right	Right
Left	Left
Menu	Menu / Home
OK	OK



