


















































Original	Recharge
 Power	 Power
 Tv/AV	 SRC
 ?	 VOD
 Mute	 MUTE
 0	 0
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--	 -/-- / EPG
 Lock	 P/C / FAV
 Zoom	 WIDE

Original	Recharge
 Hold	 Subt.
 → P ←	 V-FOR
 Mix	 MEDIA
 Text	 TEXT
 Subcode	 OPT+
 QV	 TV/R
 → S ←	 Audio
 Cancel	 EXIT
 Reveal	 BACK
 Yellow/Timer	 Yellow (C)
 Blue/Sound	 Blue (D)
 Red/Picture	 Red (A)
 Green/Clock	 Green (B)
 Up	 UP
 Down	 DOWN
 Right	 RIGHT
 Left	 LEFT



