



Original		Rechange		Original		Rechange	
	Standby		Power		9		9
	Mute		Mute / Dimmer		Music/Movie/Phot		Sound / Title
	Fav		Fav / Marker / PC		0/AV		0
	World		Smart / List		Info		Info / Angle
	TV/Radio		TV/Radio /		Vol+		Vol+
	Text		Text / Goto		P↔P		Zoom / Size
	Mail		Display / Media		P+		CH+ / Page+
	Lib		D.Menu / Top		Vol-		Vol-
	Timers		Sleep / Timer		Opt		Setup / OPT /
	1		1		P-		CH- / Page-
	2		2		Red		Red / Netflix / Search
	3		3		Green		Green / APP / Repeat
	4		4		Yellow		Yellow / YouTube / Repeat
	5		5		Blue		Blue / Prime Video / Random
	6		6		EPG		Guide / EPG / -/-
	7		7		Up		Up
	8		8		Exit		Exit / Cancel / Clear





	Original	Rechange	Original	Rechange
	Left			
	OK			
	Right			
	Menu			
	Down			
	Back			
	Subtitle			
	<<			
	Play			
	>>			
	Audio			
	Stop			
	Pause			
	Rec			

